

# DD24DA\*8

## 24" DOUBLE DISHDRAWER™

### DISHWASHER™

With over a decade of DishDrawer™ dishwasher manufacture behind us, we have found new ways to make your dishwashing easier. Folding racks and tines ensure good versatility, plus a range of wash programmes and independently operated drawers, makes the ultimate clean up companion.



|  |  |
|--|--|
| <b>MODEL</b>                               | <b>DD24DAX8</b><br><b>DD24DAW8</b>   |
| <b>Colour</b>                              | Stainless steel, White   |
| <b>SKU codes</b>                           | Stainless steel: 88657, White: 88656   |
| <b>UPC codes</b>                           | Stainless steel: 822843886579,<br>White: 822843886562  |
| <b>Capacity</b>                            | Seven place settings per drawer  |
| <b>Water Usage</b>                         | 1.7 gallons  |
| <b>Energy Usage</b>                        | Energy Star™ approved (rated CEE Tier 1)   |
| <b>FEATURES</b>                            | <b>BENEFITS</b>  |
| Ergonomic                                  | Designed with your back in mind and as easy to slide as a kitchen drawer; loading requires the absolute minimum of movement.   |
| Convenient                                 | Seven place settings per drawer. Includes a range of flexible and adjustable racking options for different wash requirements.  |
| Six Wash Programmes                        | Features a choice of six wash programmes, including heavy, normal, normal eco, fast, gentle and rinse.   |
| Easy to Use Controls                       | One single control panel for easy programming of both tubs.  |
| Flexible racking                           | Allows flexibility to customise load type. They can fold away to run a full drawer of pots, pans, woks on heavy wash, or fold up and run a delicate load of glassware and crystal. |
| Fold Up Side Racks with Wine Glass Holders | Side racks can fold away and wine glass holders care for delicate glasses.   |
| Key Lock and Child Safety Lock             | Key lock locks all the buttons on the control panel. Child lock locks the drawers closed as well as locking all the buttons on the control panel.                                  |
| Flow Through Detergent Dispenser           | Detergent goes through the world's first flow through dispenser, to ensure it is thoroughly dissolved, providing a faster, hygienic wash without detergent burn on dishes.         |
| Delay Start 1-12 Hours                     | The cycle can start in 1 hour increments up to 12 hours, so dishes can be freshly cleaned when you wake up in the morning.   |

| DIMENSIONS                                 | INCHES            |
|--|-------------------|
| Ⓐ Overall height of product                | 32 5/16 - 34 5/8" |
| Ⓑ Overall width of product                 | 23 9/16"          |
| Ⓒ Depth of product front (excludes handle) | 1 1/8"            |
| Ⓓ Depth of product chassis                 | 21 3/4"           |

For further details about sizes please refer to the installation manual.

