

August 18, 2012



#80.400 Shower Valve

In September 2011, Mustee made a change on the 80.400 Shower Valve from a 3-3/8" center to a 4" center. The 80.400 Shower Valve is used on the 80, 82, 140, 142, 70 & 30 Durastall Shower Stall Units.

Should a customer require a replacement 80.400 Shower Valve on an older Durastall Shower Stall they will have to open up the holes in the existing wall. Attached are instructions to make this change. Please provide this information to anyone inquiring about a change out.

The new 4" center 80.400 Shower Valve is a higher quality product and improves the complete unit.

Please contact Wendy at 724-704-7604 with any questions.



Preferred Sales, Inc.
1 Industrial Drive
Hermitage, PA 16148
Phone: 724-981-5500
Fax: 724-981-5560
orders@preferredsales.com
www.preferredsales.com

CONVERT/RETRO FIT PN 80.400A FAUCET 3 3/8" CENTERLINE VALVE to 4" CENTERLINE VALVE

INSTALLATION INSTRUCTIONS:

1. Turn off Hot & Cold water supply to valve and remove all lines.
2. Remove existing valve from shower unit.
3. Layout **TWO** 1" to 1 1/8" Diameter holes over the existing valve holes at 4" Centerline as shown in Fig.1
Do Not Exceed 1 1/8" Diameter. **See Provided Template**
4. Increase hole sizes by either a sanding drum (Dremel), utility knife, Roto-zip, tin snips, half round file, ect.... See Fig.2
5. Deburr holes and test fit the 4" valve.
6. Applying silicone sealer on the backside of the Flange Nuts will insure a tight seal to the shower wall as shown in Fig.3
DO NOT APPLY SEALER TO ANY THREADS ON FLANGE NUT OR VALVE BODY!
7. Install 4" valve body. The Flange Nuts will cover the increased hole diameter as shown in Fig.4
AVOID INCREASING JUST ONE HOLE - FLANGE NUTS WILL NOT COVER INCREASE HOLE OPENING.

